



Checklist storingen



Balansventilatie met warmtewisselaar (WTW)



1. Haal de stekker uit het stopcontact wacht een moment en stop hem er weer in.
2. Zit de stekker van de wtw-unit in het stopcontact?
3. Is er spanning? Controleer de zekeringen en/of aardlekschakelaar.
4. Zijn de filters schoon?
5. Zijn de batterijen van de automatische vraaggestuurde regeling in orde en is deze juist gemonteerd?
6. Staat er een storingscode in het display van uw thermostaat?

Twijfelt u?

Neem dan altijd contact met ons op.

0900 – 821 21 74*

Of kijk op breman.nl/storingoplossen

*Gebruikelijke belkosten.



Malfunction checklist



Balanced ventilation with heat exchanger (HRV)



1. Remove the plug from the power socket, wait a moment, and insert the plug into the socket again.
2. Is the plug of your HRV unit in the power socket?
3. Is there current? Check the fuses and/or earth leakage circuit breaker.
4. Are the filters clean?
5. Are the batteries of the automatic on-demand controller still good and has it been correctly mounted?
6. Is there a malfunction code on the display of your thermostat?

Are you unsure?

Then please feel free to contact us.

0900 – 821 21 74*

Or visit breman.nl/storingoplossen

* Regular calling costs.